







# Genset Control for Multiple Unit Operation

### **DESCRIPTION**

The easYgen-3000 Series are control units for genset management applications. The numerous inputs and outputs, along with a modular software structure, permit you to use the easYgen-3000 Series for a wide range of applications with only a single part number. This includes stand-by, AMF, peak shaving, import-export, cogeneration or distributed generation, among others. Also the easYgen-3000 Series is compatible for island, island parallel, mains parallel and multiple unit mains parallel operations.

The easYgen-3000 Series is able to control up to 32 gensets connected in a network with automatic sequencing.

The easYgen-3000 Series is available in two variants, the easYgen-3100 for cabinet back panel installation, and the easYgen-3200 with graphical display and soft keys for front panel mounting.

 $FlexApp^{TM}$  – This feature provides the tools to easily configure the number of operated breakers: None, GCB, GCB and MCB.

**LogicsManager**<sup>™</sup> – Woodward's LogicsManager software enables to change the operation sequences and adapt them to specific needs. The LogicsManager accomplishes this by monitoring a range of measuring values and internal states, which are combined logically with Boolean operators and programmable timers. This enables to create and/or modify control and relay functions.

FlexIn<sup>TM</sup> – The analog inputs are configurable to operate with VDO, resistive, and/or 0 to 20 mA senders.

Flexible Outputs – Speed and voltage bias outputs are configurable to function with all speed governors and voltage regulators. The outputs can also be used as freely scalable outputs (e.g. for driving external meters).

FlexCAN™ – Advanced network interfaces ensure unsurpassed control performance – from engine control up to total plant operation. The easYgen-3000 Series is capable of working with all common industrial interfaces, including CAN, RS-232, and RS-485. The multiple communication protocols permit the easYgen-3000 Series to communicate with a vast majority of engine control units (ECUs), external I/O boards, PLCs, and modems. CANopen, J1939, Modbus RTU, and Modem protocols are supported.

*DynamicsLCD™* – The adaptive and interactive 5.7", 320x240 pixel graphical LC display with soft keys and a clear menu structure ensures intuitive user operation and navigation.

#### **Features**

- Operation modes: Auto, Stop, Manual, and Load/No Load test modes via discrete input possible
- Breaker control: Slip frequency / phase matching synchronization, open-close control, breaker monitoring
- Load transfer features: open / closed transition, interchange, soft loading / soft unloading, mains parallel
- Process and load-dependent start/stop logic for diesel and gas engines programmable for spinning or system reserve with fixed or dynamic priorities.
- Real and reactive power load sharing with up to 32 units
- Remote control via interface and discrete/analog inputs for adjusting speed, frequency, voltage, power, reactive
  power, and power factor set points
- Complete integrated engine and generator protection as well as mains monitoring features
- Freely configurable PID controllers for various control purposes, such as heating circuit control (CHP applications), water level, fuel level, or pressure and/or other process values
- Special Scania S6, MTU ADEC, Volvo EMS2 & EDC4, Deutz EMR2, MAN MFR/EDC7, SISU EEM, Cummins and Woodward EGS02 ECU support (depending on Package)
- Counters for operating hours / engine starts / maintenance / active energy / reactive energy
- Configurable trip levels / delay timers / alarm classes for monitoring and protective functions
- Clear text display and evaluation of up to 100 J1939 analog values
- Discrete and analog I/O expansion board connectivity (Woodward IKD 1 or Phoenix Contact IL series)
- Front panel and PC configurable (ToolKit software)
- Multi-level password protection for access via HMI or interface
- Multi-lingual capability (English, German, French, Spanish, Chinese, Japanese, Italian, Portuguese, Turkish, Russian, Polish)
- Event recorder (300 events, FIFO) with real time clock

- Peak shaving operation
- Stand-by operation
- AMF operation
- Cogeneration (CHP)
- Isolated & mains parallel operation
- Import/export control
- Soft loading features
- Open/closed transition
- Load sharing and loaddependent start/stop for up to 32 units
- Programmable operation sequences
- Multi-lingual capability
- CANopen / J1939 ECU Control
- Modbus RTU Protocol
- CE marked
- UL/cUL Listing
- LR & ABS Marine


# **SPECIFICATIONS**

Power supplyIntrinsic consumption	12/24 Vdc (8 to 40 Vdc)
Ambient temperature (operation)	-20 to 70 °C / -4 to 158 °F
Ambient temperature (storage)	-30 to 80 °C / -22 to 176 °F
Ambient humidity	95 % non-condensing
Ambient humidity  Voltage	( 1/A)
100 Vac [1] Rated (V <sub>rated</sub> )	60/120 Vac
Max. value (V <sub>max</sub> )	
Rated surge volt.(V <sub>surge</sub> )	
and 400 Vac [4] Rated (Vrated)	
Max. value (V <sub>max</sub> )	
Rated surge volt.(V <sub>surge</sub> )	
Accuracy	
Measurable alternator windings 3p-3w, 3p-4	
Softing range primary	50 to 650 000 Vac
Setting range primary primary	
Linear measuring range	E0/40 Hz (40 to 95 Hz)
Measuring frequency	
High Impedance Input; Resistance per path	
Max. power consumption per path	< 0.15 W
Current (Isolated) Rated (Irated)	
Linear measuring range	ů .
	$I_{\text{mains/ground}} = 1.5 \times I_{\text{rated}}$
Setting range	1 to 32,000 A
Burden	
Rated short-time current (1 s)	[1] 50×I <sub>rated</sub> , [5] 10×I <sub>rated</sub>
Power	
Setting range	0.5 to 99,999.9 kW/kvar
Discrete inputs	isolated
Input range	
Input resistance	
•	


Contact material Load (GP)	isolatedAgCdO 2.00 Aac@250 Vac Adc@24 Vdc / 0.36 Adc@125 Vdc / 0.18 Adc@250 Vdc
	Adc@24 Vdc / 0.22 Adc@125 Vdc / 0.10 Adc@250 Vdc
Analog inputs (non	e isolated)freely scaleable 0 to 500 Ohms / 0 to 20 mA
	11 Bit blated)freely scaleable
	± 10 V / ± 20 mA / PWM
	ontinuously)100 Vac
	e (1s)
	internal resistance ≤1 kOhms
	maximum load 500 Ohms
Housing (3200)	Front panel flush mounting Plastic housing
Dimensions	WxHxD 282 × 217 × 99 mm
Front cutout	WxH249 [+1.1] × 183 [+1.0] mm
	screw/plug terminals 2.5 mm <sup>2</sup>
	insulating surface
Sealing	FrontIP66 (with screw fastening)
	FrontIP54 (with clamp fastening)
	BackIP20
Weight	Switch cabinet back mountingSheet metal housing
Housing (3100)	Switch cabinet back mountingSneet metal nousing
	WxHxD
Disturbance test (C	E) tested according to applicable EN guidelines
	LR (Type Approval), ABS (Design Assessment)


# **DIMENSIONS**

## Plastic housing for front panel mounting (3200)



# Metal housing for cabinet mounting (3100)





			Serial #2 RS-485 isolated (Interface #2)		Serial #1 RS-232 isolated (Interface #1)		
	40	400 Vac	Busbar Voltage (system 1) L2   N	WOODWAR.	Relay [R 01] isolated "1 Fixed to "Ready for operation"	[R 01]	42 41
	38 3	400 Vac	Busbar Voltage (system 1) L1		Relay [R 02] isolated " Preconfigured to "Centralized alarm" Relay [R 03] isolated "	[R 02]	43
	36 37	100 Vac 400 Vac			Preconfigured to "Starter"  Relay [R 04] isolated *1  Preconfigured to "Fuel solenoid / gas valve"	[R 03]	45 44
	35	100 Vac	Generator Voltage N				46
	33 34	400 Vac 100 Vac	Generator Voltage L3		Relay [R 05] isolated "1 Preconfigured to "Preglow"	[R 05]	48 47
	32	400 Vac	Generator Voltage L2		Relay [R 06] isolated "1 Preconfigured to "Command: close GCB"	[R 06]	49
	30 31	100 Vac 400 Vac					51 50
	29	100 Vac	Generator Voltage L1	Generator Voltage L1	Relay [R 07] isolated "1 Preconfigured to "Command: open GCB"	[R 07]	52
	27 28	400 Vac 100 Vac	Mains Voltage N		Relay [R 08] isolated "1 Preconfigured to "Command: close MCB"	[R 08]	54 53
	5 26	400 Vac	Mains Voltage L3		Relay [R 09] isolated "1 Preconfigured to "Command: open MCB"	[R 09]	26 55
	24 2	400 Vac	Mains Voltage L2		Relay [R 10] isolated "1 Preconfigured to "Auxiliary services"	[R 10]	57 5
	23	100 Vac		_	Relay [R 11] isolated " Preconfigured to "Alarm class A or B"  Relay [R 12] isolated "	[R 11]	28
PWM DC oltage DC urrent	21   22	400 Vac 100 Vac	Mains Voltage L1		Preconfigured to "larm class C, D, E or F"	[R 12]	09
GND → GND → O	20	-		Protective Earth PE		<u></u>	
		[AO 02]			Engine ground		₩ 8
GND VO	17 18 19	[AO 02] + -	Analog outputs +/-10 Vdc   +/-20 mA   PWM isolated		Engine ground  Power supply 8 to 40 Vdc	12/24	
4-0-	16 17 18	[AO 02] + - [AO 01]	+/-10 Vdc   +/-20 mA   PWM		Power supply 8 to 40 Vdc  Auxiliary excitation isolated	12/24 0	Vdc P9 P+ 9
PWM GNU   PWM	+ [AO 01] +	+/-10 Vdc   +/-20 mA   PWM		Power supply 8 to 40 Vdc  Auxiliary excitation isolated  Common (terminals 67 to 78)  Discrete input [DI 01] isolated	12/24 0	Vdc 99 P+ 99	
4-0-	14 15 16 17 18	+ [AO 01]	+/-10 Vdc   +/-20 mA   PWM		Power supply 8 to 40 Vdc  Auxiliary excitation isolated  Common (terminals 67 to 78)	12/24 0	Vdc 99 P+ 99
4-0-	12 13 14 15 16 17 18	+ [AO 01] +	+/-10 Vdc   +/-20 mA   PWM		Power supply 8 to 40 Vdc  Auxiliary excitation isolated  Common (terminals 67 to 78)  Discrete input [DI 01] isolated " Emergency stop  Discrete input [DI 02] isolated " Start in Auto  Discrete input [DI 03] isolated " Low oil pressure	[DI 01] [DI 02] [DI 03] [DI 03]	Vdc
4-0-	11 12 13 14 15 16 17 18	+ [AO 01] + [AI 03]	+/-10 Vdc   +/-20 mA   PWM isolated		Power supply 8 to 40 Vdc  Auxiliary excitation isolated Common (terminals 67 to 78)  Discrete input [DI 01] isolated TEmergency slop Discrete input [DI 02] isolated Temergency slop Using the input [DI 03] isolated Temergency slop Discrete input [DI 03] isolated Temergency slop Discrete input [DI 04] isolated Temergency in pressure Discrete input [DI 04] isolated Temergency Slope Sl	[DI 01] [X [DI 02] [X [DI 04] [X	Vdc P9 99 L9 89 69 0Z
4-0-	10 11 12 13 14 15 16 17 18	+ [AO 01] + [AI 03] - [AI 02]	+/-10 Vdc   +/-20 mA   PWM isolated		Power supply 8 to 40 Vdc  Auxiliary excitation isolated  Common (terminals 67 to 78)  Discrete input [DI 01] isolated " Emergency stop  Discrete input [DI 02] isolated " Start in Auto Discrete input [DI 03] isolated " Low oil pressure  Discrete input [DI 04] isolated " Coolant temp.	[DI 01] [22] [DI 02] [22] [DI 03] [22] [DI 04] [23]	Vdc
4-0-	09 10 11 12 13 14 15 16 17 18	+ [AO 01] + [AI 03] - [AI 02]	+/-10 Vdc   +/-20 mA   PWM isolated		Power supply 8 to 40 Vdc  Auxiliary excitation isolated  Common (terminals 67 to 78)  Discrete input [DI 01] isolated "1 Emergency stop  Discrete input [DI 02] isolated "1 Start in Auto  Discrete input [DI 03] isolated "1 Low oil pressure  Discrete input [DI 04] isolated "1 Coolant temp.  Discrete input [DI 05] isolated "1 Alarm acknowledge  Discrete input [DI 06] isolated "1 Enable MCB  Discrete input [DI 06] isolated "1 Enable MCB  Discrete input [DI 07] isolated Reply: MCB open	[DI 01] [X [DI 02] [X [DI 04] [X [DI 06] [X [DI 06]] [X [DI 06]] [X [DI 06]]	A
4-0-	07 08 09 10 11 12 13 14 15 16 17 18	+ [AO 01] + [AI 03] - [AI 02] - [AI 01] - \$1 L3	+/-10 Vdc   +/-20 mA   PWM isolated	S	Power supply 8 to 40 Vdc  Auxiliary excitation isolated  Common (terminals 67 to 78)  Discrete input [DI 01] isolated "1 Emergency stop  Discrete input [DI 02] isolated "1 Start in Auto  Discrete input [DI 03] isolated "1 Low oil pressure  Discrete input [DI 04] isolated "1 Coolant temp.  Discrete input [DI 05] isolated "1 Alarm acknowledge  Discrete input [DI 06] isolated "1 Enable MCB  Discrete input [DI 07] isolated Reply: MCB open  Discrete input [DI 07] isolated Reply: MCB open  Discrete input [DI 08] isolated Reply: MCB open	[DI 01] [X   DI 02] [X   DI 03] [X   DI 06] [X   DI 06] [X   DI 06] [X   DI 08] [X   DI 08]	74 73 72 71 70 69 68 67 66 65 64 63
4-0-	06 07 08 09 10 11 12 13 14 15 16 17 18	+ (AO 01) + (AI 03) - (AI 02) - (AI 01) - s1 L3	+/-10 Vdc   +/-20 mA   PWM isolated	S	Power supply 8 to 40 Vdc  Auxiliary excitation isolated  Common (terminals 67 to 78)  Discrete input [DI 01] isolated " Emergency stop  Discrete input [DI 02] isolated " Start in Auto Discrete input [DI 03] isolated " Low oil pressure  Discrete input [DI 04] isolated " Coolant temp.  Discrete input [DI 05] isolated " Alarm acknowledge Discrete input [DI 06] isolated " Enable MCB Discrete input [DI 07] isolated Reply: MCB open Discrete input [DI 08] isolated Reply: GCB open  Discrete input [DI 08] isolated Reply: GCB open	[DI 01] [22] [DI 02] [22] [DI 03] [22] [DI 04] [22] [DI 05] [22] [DI 06] [22] [DI 07] [22] [DI 08] [22]	75 74 73 72 71 70 69 68 67 66 65 64 63
4-0-	07 08 09 10 11 12 13 14 15 16 17 18	+ [AO 01] + [AI 03] - [AI 02] - [AI 01] - S1 L3 S2 S1 L2 S2 S1	+/-10 Vdc   +/-20 mA   PWM isolated  Analog inputs 0 to 500 Ohms   0/4 to 20 mA	S	Power supply 8 to 40 Vdc  Auxiliary excitation isolated  Common (terminals 67 to 78)  Discrete input [DI 01] isolated "1 Emergency stop  Discrete input [DI 02] isolated "1 Start in Auto  Discrete input [DI 03] isolated "1 Low oil pressure  Discrete input [DI 04] isolated "1 Coolant temp.  Discrete input [DI 05] isolated "1 Alarm acknowledge  Discrete input [DI 06] isolated "1 Enable MCB  Discrete input [DI 07] isolated Reply: MCB open  Discrete input [DI 07] isolated Reply: MCB open  Discrete input [DI 08] isolated Reply: MCB open	[DI 01] [X] [DI 02] [X] [DI 03] [X] [DI 04] [X] [DI 06] [X] [DI 06] [X] [DI 08] [X] [DI 09] [X]	74 73 72 71 70 69 68 67 66 65 64 63
4-0-	05 06 07 08 09 10 11 12 13 14 15 16 17 18	+ [AO 01] + [AI 03] - [AI 02] - [AI 01] - s1 L3 s2 s1 L2 s2	+/-10 Vdc   +/-20 mA   PWM isolated  Analog inputs 0 to 500 Ohms   0/4 to 20 mA	S	Power supply 8 to 40 Vdc  Auxiliary excitation isolated  Common (terminals 67 to 78)  Discrete input [DI 01] isolated "1 Emergency stop  Discrete input [DI 02] isolated "1 Start in Auto  Discrete input [DI 03] isolated "1 Low oil pressure  Discrete input [DI 04] isolated "1 Coolant temp.  Discrete input [DI 05] isolated "1 Alarm acknowledge  Discrete input [DI 06] isolated "1 Enable MCB  Discrete input [DI 07] isolated Reply: MCB open  Discrete input [DI 07] isolated Reply: GCB open  Discrete input [DI 08] isolated "1 Discrete input [DI 09] isolated "1	[DI 01] [2] [DI 02] [2] [DI 03] [2] [DI 05] [2] [DI 06] [2] [DI 08] [2] [DI 09] [2] [DI 10] [2] [DI 11] [2] [2]	76 75 74 73 72 71 70 69 68 67 66 65 64 63
4-0-	02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18	+	+/-10 Vdc   +/-20 mA   PWM isolated  Analog inputs 0 to 500 Ohms   0/4 to 20 mA	gen-3000 Series	Power supply 8 to 40 Vdc  Auxiliary excitation isolated  Common (terminals 67 to 78)  Discrete input [DI 01] isolated "Emergency stop  Discrete input [DI 02] isolated "Start in Auto Discrete input [DI 03] isolated "Low oil pressure  Discrete input [DI 04] isolated "Coolant temp.  Discrete input [DI 05] isolated "Alarm acknowledge  Discrete input [DI 06] isolated "Enable MCB  Discrete input [DI 07] isolated  Reply: MCB open  Discrete input [DI 08] isolated  Reply: GCB open  Discrete input [DI 09] isolated  Reply: GCB open  Discrete input [DI 09] isolated "Discrete input [DI 09] isolated "Discrete input [DI 10] isolated "Discrete input [DI 11] isolated "	[DI 01] [2] [DI 02] [2] [DI 03] [2] [DI 05] [2] [DI 06] [2] [DI 08] [2] [DI 09] [2] [DI 10] [2] [DI 11] [2] [2]	+ + + + + + + + + + + + + + + + + + +
4-0-	03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18	+ [AO 01] + [AI 03] - [AI 02] - [AI 01] - S1 L3 S2 S1 L2 S2 S1 L1 S2	+/-10 Vdc   +/-20 mA   PWM isolated  Analog inputs 0 to 500 Ohms   0/4 to 20 mA  Generator current isolated	asYgen-3000 Series	Power supply 8 to 40 Vdc  Auxiliary excitation isolated  Common (terminals 67 to 78)  Discrete input [DI 01] isolated "Emergency stop  Discrete input [DI 02] isolated "Start in Auto Discrete input [DI 03] isolated "Low oil pressure  Discrete input [DI 04] isolated "Coolant temp.  Discrete input [DI 05] isolated "Alarm acknowledge  Discrete input [DI 06] isolated "Enable MCB  Discrete input [DI 07] isolated Reply: MCB open  Discrete input [DI 08] isolated  Reply: MCB open  Discrete input [DI 09] isolated  Tobic rete input [DI 09] isolated "Discrete input [DI 10] isolated "Discrete input [DI 10] isolated "Discrete input [DI 10] isolated "Discrete input [DI 11] isolated "Discrete input [DI 11] isolated "Discrete input [DI 12] isolated "Discrete input [	[DI 01] [2] [DI 02] [2] [DI 03] [2] [DI 05] [2] [DI 06] [2] [DI 08] [2] [DI 09] [2] [DI 10] [2] [DI 11] [2] [2]	78 77 76 75 74 73 72 71 70 69 68 67 66 65 64 63



#### International

Woodward PO Box 1519 Fort Collins CO, USA 80522-1519 1000 East Drake Road Fort Collins CO 80525 Ph: +1 (970) 482-5811 Fax: +1 (970) 498-3058

#### Europe

Woodward GmbH Handwerkstrasse 29 70565 Stuttgart, Germany Ph: +49 (0) 711 789 54-0 Fax: +49 (0) 711 789 54-100 email: stgt-info@woodward.com

Distributors & Service Woodward has an international network of distributors and service facilities. For your nearest representative, call the Fort Collins plant or see the Worldwide Directory on our website.

#### www.woodward.com/power

For more information contact:

Subject to technical modifications.

This document is distributed for informational purposes only. It is not to be construed as creating or becoming part of any Woodward Governor Company contractual or warranty obligation unless expressly stated in a written sales contract.

We appreciate your comments about the content of our publications. Please send comments including the document number below to stgt-doc@woodward.com

#### © Woodward

#### **All Rights Reserved**

37258G - 2010/05/Stuttgart

## **FEATURES OVERVIEW**

711	anaVana 2000 Sarian			
FACVICEN	easYgen-3000 Series			
(EASY) GEN Model		00	32	
3000 Package	P1	P2	P1	P2
Measuring		,		
Generator voltage (3-phase/4-wire) Generator current (3x true r.m.s.)	✓ ✓	✓ ✓	<b>√</b>	✓ ✓
Mains voltage (3-phase/4-wire)	<b>∨</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Mains or ground current (1x true r.m.s.) #1	<b>✓</b>	<b>✓</b>	· ·	· ·
Busbar voltage (1-phase/2-wire)	· ✓	<b>√</b>	<b>✓</b>	<b>✓</b>
Control				- <u>-</u>
Breaker control logic (open and closed transition) FlexApp™	2	2	2	2
Automatic, Manual, Stop, and test operating modes	<u> </u>	<u>-</u>	<u> </u>	<u>−</u>
Single and multiple-unit operation	✓	✓	✓	✓
Mains parallel multiple-unit operation (up to 32 units)	✓	<b>√</b> #2	✓	<b>√</b> #2
AMF (auto mains failure) and stand-by operation	✓ ✓	✓ ✓	✓ ✓	✓ ✓
Critical mode operation GCB and MCB synchronization (slipping / phase matching)	<b>✓</b>	<b>✓</b>	<b>✓</b>	<b>✓</b>
Interchange (import / export control)	<b>✓</b>	<b>✓</b>	<b>∨</b>	<b>√</b>
Load-dependent start/stop	✓	<b>√</b>	✓ ·	✓
n/f, V, P, Q, and PF remote control via analog input or interface	<b>√</b>	✓	<b>✓</b>	✓
Load/var sharing for up to 32 gensets	✓	✓	✓	✓
Freely configurable PID controllers	-	3	-	3
НМІ				
Soft keys (advanced LC display) DynamicsLCD™	-	-	✓	✓
Start/stop logic for diesel / gas engines	✓	✓	✓	✓
Counters for operating hours / starts / maintenance / active/reactive energy	✓	<b>√</b>	✓	<b>√</b>
Configuration via PC *3	200	√ 200	200	200
Event recorder entries with real time clock (battery backup)	300	300	300	300
Protection ANSI#	1	,		
Generator: voltage / frequency 59 / 27 / 810 / 81U	✓ ✓	✓ ✓	✓ ✓	✓ ✓
Generator: overload, reverse/reduced power 32 / 32R / 32F Generator: unbalanced load 46	<b>∨</b>	<b>✓</b>	<b>∨</b>	<b>✓</b>
Generator: instantaneous overcurrent 50	<b>✓</b>	<b>✓</b>	· ·	· ·
Generator: time-overcurrent (IEC 255 compliant) 51	· ✓	<b>√</b>	<b>✓</b>	✓ ·
Generator: ground fault #4 50G	✓	✓	✓	✓
Generator: power factor 55	✓	✓	✓	✓
Generator: rotation field	✓	✓	<b>✓</b>	<b>√</b>
Engine: overspeed / underspeed 12 / 14	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>
Engine: speed / frequency mismatch	✓ ✓	✓ ✓	✓ ✓	✓ ✓
Engine: D+ auxiliary excitation failure  Mains: voltage / frequency  59 / 27 / 810 / 81U	<b>✓</b>	<b>V</b> ✓	<b>✓</b>	<b>✓</b>
Mains: phase shift / rotation field 78 /	· ✓	· ✓	· ·	<b>✓</b>
I/Os				-
Speed input (magnetic / switching; Pickup)	<b>√</b>	<b>√</b>	<b>√</b>	✓
Discrete alarm inputs (configurable)	10	10	10	10
Discrete outputs (configurable) LogicsManager™	max. 12	max. 12	max. 12	max. 12
External discrete inputs / outputs via CANopen (maximum)	16 / 16	32 / 32	16 / 16	32 / 32
Analog inputs <sup>#5</sup> (configurable) FlexIn™	3	3	3	3
Analog outputs (+/- 10V, +/- 20mA, PWM; configurable)	2	2	2	2
External analog inputs / outputs via CANopen (maximum)	- 1/	16 / 4	- 1/	16 / 4
Display of J1939 analog values (number of SPNs) Display and evaluation of J1939 analog values (supported SPNs)	16	100	16	100
CAN bus communication interfaces #6 FlexCAN <sup>TM</sup>	2	2	2	2
RS-232/485 Modbus RTU Slave interface(s)	1/1	1/1	1/1	1/1
Listings/Approvals				
UL Listing	✓	✓	✓	✓
cUL Listing	✓	✓	-	-
LR & ABS Marine	✓	✓	✓	✓
CE Marked	✓	✓	✓	✓
Part Numbers				
1A CT inputs / front panel mounting with display #7 P/N 8440-	-	-	1922	1924
5A CT inputs / front panel mounting with display #7 P/N 8440-	-	-	1923	1925
1A CT inputs / cabinet back mounting w/o display P/N 8440-	1931	1933	-	-
5A CT inputs / cabinet back mounting w/o display P/N 8440- Spare connector kit P/N 8923-	1930	1932	121/	1211
Spare connector kit P/N 8923-	1314	1314	1314	1314
#1 mains or ground current selectable #5 selectable during configuration between	en VDO (0 to 180 (	Ohm. 0 to 5 bar). VD	O (0 to 180 Ohm. 0	to 10 har) VDO

- mains or ground current selectable refer to the Application Manual 37471 for applications with more than 8 parallel gensets
- measured ground current
- selectable during configuration between VDO (0 to 180 Ohm, 0 to 5 bar), VDO (0 to 180 Ohm, 0 to 10 bar), VDO (0 to 380 Ohm, 40 to  $120^{\circ}\text{C}$ ), VDO (0 to 380 Ohm, 50 to  $150^{\circ}\text{C}$ ), Pl100, Resistive input (one- or two-pole, 2pt. linear or 9pt. user defined ), or 20 mA (0/4 to 20 mA, freely configurable)
- because of bus load limits
  via serial connection and ToolKit software (included)
  #7 freely selectable during configuration between CANopen or J1939; request information
  a screw and a clamp kit are delivered with the unit for fastening